Instruction and Safety Manual

Outfitter Adjustable Hunting Chair

MODEL: OT-900

Thank you very much for choosing

OL'MAN TREESTANDS

We appreciate your business!

⚠ WARNING ⚠

ONLY USE AT GROUND LEVEL.

Outfitter Adjustable Hunting Chair

MODEL: OT-900

PARTS LIST

A	1 Seat	Part # OTS-900
B	1 Seat Base	Part # OTCB-900
C	2 Arm Rest	Part # OTAR-900

HARDWARE LIST

D	1 M8 Quickclip	Part # OTQC-1616
26	4 M6 x 30mm bolts w/washers	Part # 1026
56	2 M6 x 55mm bolts with knobs	Part # 1056
61	2 M6 x 60mm bolts with knobs	Part # 1061

A Seat

B Seat Base

C Arm Rest (2)

D M8 Quickclip

E Arm Rest 55mm Bolts with knobs (2)

F Arm Rest 60mm Bolts with knobs (2)

Distributed by Ol' Man Treestands, 201 Fairmont Plaza, Pearl MS 39208

©2025 (rev. 1/25)

Assembly Instructions

Model: OT-900
Outfitter Adjustable Hunting Chair



1 Attach the Seat **A** to the Seat Base **B** using ***4 - M6 x 30mm bolts w/ metal washers*** 26**.**



2 Stand Chair upright onto the legs. Raise the center post of the Seat Base to the desired height and insert the M8 Quickclip **D** as shown.



3 Attach the Arm Rest **C** to the Seat **A** using ***1 -M6 x 60mm bolts*** 61 on the back rest of the Seat **A** and ***1 - M6 x 55mm bolts*** 56 on the bottom of the Seat **A**. **NOTE: Place the spacer in between the Seat A and Arm Rest C.** Repeat these steps for other Arm Rest.

4 Use the lever lock as shown above to adjust the leg height of the chair.

⚠ WARNING ⚠

ONLY USE AT GROUND LEVEL.

Distributed by Ol' Man Treestands, 201 Fairmont Plaza, Pearl MS 39208

©2025 (rev. 1/25)